



## 16.4V VOLTAGE REGULATOR WIRING DIAGRAM

This diagram shows one method detailing a basic installation of the Norsk Lithium 16.4V regulator. Your installation may present unique challenges due to the battery selected, space limitations, and the accessories to be powered. This diagram is not to be considered universal installation instructions that cover all scenarios. Please consult a rigging professional or electrician if you are unqualified to perform the installation or contact Norsk Lithium customer service for assistance.